

78 toeren platen afspelen op een Pro-Ject platenspeler:


- ◆ · Pro-Ject biedt diverse platenspelers om 78 toeren platen af te spelen
- ◆ · Op de volgende pagina's treft u een uitgebreid overzicht aan van alle Pro-Ject draaitafels met de mogelijk én onmogelijkheden
- ◆ · Enkelen zijn geschikt voor alle snelheden (A), zonder gebruik van additionele accessoires
- ◆ · De meeste hebben additionele accessoires nodig (B, C of D)
- ◆ · Enkelen zijn ongeschikt voor het afspelen van 78 toeren platen (E).
- ◆ · LET OP!: Het afspelen van 78 toeren platen met een standaard naald kan de naaldtip beschadigen! Speciaal hiervoor verkrijgbare 78-toeren naaldjes zijn verkrijgbaar voor MM elementen! (zie voorbeelden >>>)
- ◆ · Het verwisselen van de aandrijfpulley is vrij eenvoudig!
- ◆ · Indien er enige twijfel bestaat, raadpleeg uw Pro-Ject dealer!

ortofon OM-78
naald




◆◆ Voor het afspelen van 78rpm platen dient u de naald te vervangen ◆◆

ortofon 2M-78
naald



A: 33 & 45 & 78
Deze draaitafels zijn standaard al geschikt voor het afspelen op alle snelheden




12" record 33rpm 10" record 78rpm 7" single 45rpm

B: 33 & 78
De standaard pulley dient vervangen te worden door een 78 rpm pulley (+snaar)




78rpm set: pulley + snaar (geen 45rpm mogelijk!)

C: 33 & 45 & 78
Toevoeging van de Speed Box S en vervangen van de standaard pulley voor de "Pulley SB"



Speed Box S + Pulley SB

D: 33 & 45 & 78
Toevoeging van de Speed Box DS en vervanging van de standaard pulley voor de "Pulley SB"




Speed Box DS + Pulley SB

| currently available turntables: | 33/45/78rpm out of the box | 33/78rpm (no 45) by adding "78 Pulley Set" | 33/45/78rpm by adding Speed Box S & "Pulley SB" | 33/45/78rpm by adding Speed Box SE & "Pulley SB" | 78rpm not available | recommended 78 stylus suitable for pre-mounted cartridge |
|--|-------------------------------|--|--|---|------------------------|--|
| | A | B | C | D | E | |
| 1 Anny (20 Jahre PJ)/OrtSuperOM10 | | ✓ | ✓ | ✓ | | OM78 |
| Essential/Ort OM5E | | | | | ✓ | |
| Essential/Phono USB/Ort OM5E | | | | | ✓ | |
| Essential Basic/Ort OM5E | | | | | ✓ | |
| Essential Basic/Phono USB/Ort OM5E | | | | | ✓ | |
| Essential Premium/Ort 2M Blue | | | | | ✓ | |
| Essential Premium/Phono USB/Ort 2M Blue | | | | | ✓ | |
| Debut III/Ort OM5E | | ✓ | ✓ | ✓ | | OM78 |
| Debut III E/Ort OM5E | | ✓ | ✓ | ✓ | | OM78 |
| Debut III Phono USB/Ort OM5E | | ✓ | | | | OM78 |
| Debut III Phono SB/Ort OM5E | ✓ | | | | | OM78 |
| Debut III Esprit/Ort Alpha | | ✓ | ✓ | ✓ | | ** |
| Debut SE II/Ort 510MkII | | ✓ | ✓ | ✓ | | ** |
| Debut III SE/Ort OM10 | | ✓ | ✓ | ✓ | | OM78 |
| Debut Carbon Int-230 volt (Basic)/Ort OM10 | | ✓ | | ✓ | | OM78 |
| Debut Carbon Int-230 volt (Basic)/PhUSB/Ort OM10 | | ✓ | | ✓ | | OM78 |
| Debut Carbon Int-230 volt (Premium)/Ort 2M Red | | ✓ | | ✓ | | 2M78 |
| Debut Carbon Esprit Int-230 volt /Ort 2M Red | | ✓ | | ✓ | | 2M78 |
| Debut Carbon US-16 volt (Basic)/Ort OM10 | | ✓ | ✓ | ✓ | | OM78 |
| Debut Carbon US-16 volt (Basic)/PhUSB/Ort OM10 | | ✓ | ✓ | ✓ | | OM78 |
| Debut Carbon US-16 volt (Premium)/Ort 2M Red | | ✓ | ✓ | ✓ | | 2M78 |
| Debut Carbon Esprit US-16 volt /Ort 2M Red | | ✓ | ✓ | ✓ | | 2M78 |
| Juke Box/Ort OM 5E | | ✓ | ✓ | ✓ | | OM78 |
| Juke Box Esprit/Ort Alpha | | ✓ | ✓ | ✓ | | ** |
| 1 Xpression III | | ✓ | ✓ | ✓ | | ** |
| 1 Xpression III/Ort 2M Red | | ✓ | ✓ | ✓ | | 2M78 |
| 1 Xpression III C/Ort 2M Red | | ✓ | ✓ | ✓ | | 2M78 |
| 1 Xpression III C 78/Ort Super OM10 | | ✓ | ✓ | ✓ | | OM78 |
| 1 Xpression Classic | | ✓ | ✓ | ✓ | | ** |
| 1 Xpression Classic/Ort 2M Red | | ✓ | ✓ | ✓ | | 2M78 |
| 2 Xperience Comfort/Ort 2M Red | | | | | ✓ | |
| 2 Xperience Basic +/-Ort MC 25 E | | | | | ✓ | |
| Aspect 2011 - wie Xperience Basic + | | | | | ✓ | |
| 2 Xperience Classic/Acryl | | | | | ✓ | |
| 2 Xperience Acryl SP1/Ort Rondo Red | | | | | ✓ | |
| 2 Xperience Acryl SP2/Ort Salsa | | | | | ✓ | |
| 2 Xperi Classic/Acryl/Sum Blue P No. 2 | | | | | ✓ | |
| 2 Xperi Classic/Ort Rondo Red | | | | | ✓ | |
| 2 Xperi Classic Acryl/Ort Rondo Red | | | | | ✓ | |
| 2 Xperi Classic/Ort 2M Red | | | | | ✓ | |
| 2 Xperi Classic Acryl/Ort 2M Red | | | | | ✓ | |
| 2 Xperi Classic SP/Ort 2M Bronze | | | | | ✓ | |
| 2 Xperi Classic Acryl SP/Ort 2M Bronze | | | | | ✓ | |
| 2 Xperi Classic SP/Ort 2M Bronze | | | | | ✓ | |
| 2 Xperi Classic Acryl SP/Ort 2M Bronze | | | | | ✓ | |
| 6 PerspeX | | | | | ✓ | |
| 6 PerspeX SP/Ort Valencia | | | | | ✓ | |
| 6 PerspeX Anny/Ort Valencia | | | | | ✓ | |
| 6 PerspeX Anny/Ort MC30SupermkII | | | | | ✓ | |
| Xtension 10 Evolution/Sum Blue P No. 2 | ✓ | | | | | ** |
| Xtension 9 Evolution | ✓ | | | | | ** |
| Xtension 12 Evolution | ✓ | | | | | ** |
| RPM 1.3 Genie/Ort OM3E | | | | | ✓ | |
| RPM 1.3 Genie/Ort 2M Red | | | | | ✓ | |
| RPM 5/Ort 2M Red | | ✓ | ✓ | ✓ | | 2M78 |
| RPM 5 SP/Ort Salsa | | ✓ | ✓ | ✓ | | ** |
| RPM 5.1 SP/Ort 2M Blue | | ✓ | ✓ | ✓ | | 2M78 |
| RPM 5.1 | | ✓ | ✓ | ✓ | | ** |
| RPM 5.1/Ort 2M Red | | ✓ | ✓ | ✓ | | 2M78 |
| RPM 5.1 SP/PJ Pick it MC1H | | ✓ | ✓ | ✓ | | ** |
| RPM 6.1 SB | ✓ | | | | | ** |
| RPM 6.1 SB SP/Ort Samba | ✓ | | | | | ** |
| RPM 9.1 | | | | | ✓ | |
| RPM 9.1 Acryl | | | | | ✓ | |
| RPM 9.1 SP 1/Ort Rondo Red | | | | | ✓ | |
| RPM 9.1 SP 2/Sum Blue P No. 2 | | | | | ✓ | |
| RPM 9.2 Evolution | | | | | ✓ | |
| RPM 10.1 Evolution | | | | | ✓ | |
| Signature | | | | | ✓ | |

| discontinued turntables: | 33/45/78rpm out of the box | 33/78rpm (no 45) by adding "78 pulley set" | 33/45/78rpm by adding Speed Box S & "Pulley SB" | 33/45/78rpm by adding Speed Box SE & "Pulley SB" | 78rpm not available | recommended 78 stylus suitable for pre-mounted cartridge |
|--------------------------------------|-------------------------------|--|--|---|------------------------|--|
| | A | B | C | D | E | |
| 0.5 | | ✓ | ✓ | ✓ | | ** |
| 0.5 Phono | | ✓ | | | | ** |
| Debut/Ort OM5E | | ✓ | ✓ | ✓ | | OM78 |
| Debut II/Ort OM5E | | ✓ | ✓ | ✓ | | OM78 |
| Debut II (III) Phono/Ort OM5E | | ✓ | | | | OM78 |
| Debut SE II/Ort 510MkII | | ✓ | ✓ | ✓ | | ** |
| 1 | | ✓ | ✓ | ✓ | | ** |
| 1.2 | | ✓ | ✓ | ✓ | | ** |
| 1.2.E | | ✓ | | | | ** |
| 1.2 C/Sum Oyster | | ✓ | ✓ | ✓ | | ** |
| 1 Xpression | | ✓ | ✓ | ✓ | | ** |
| 1 Xpression II | | ✓ | ✓ | ✓ | | ** |
| 1 Xpression II/AT 95E | | ✓ | ✓ | ✓ | | ** |
| 1 Xpression III/AT AT95E | | ✓ | ✓ | ✓ | | ** |
| 1 Xpression III C/AT AT95E | | ✓ | ✓ | ✓ | | ** |
| 2 | | ✓ | ✓ | ✓ | | ** |
| 2 Xperience SP/ OrtMC15SupmkII | | | | | ✓ | |
| 2 Xperience C/Ort 510MkII | | | | | ✓ | |
| 2 Xperience | | | | | ✓ | |
| 2 Xperience SP1/Ort Rondo Red | | | | | ✓ | |
| 2 Xperience SP2/Ort Salsa | | | | | ✓ | |
| 2 Xperience Comf/Sum Blue P No. 2 | | | | | ✓ | |
| 2 Xperience Comfort/Ort Rondo Red | | | | | ✓ | |
| RPM 1 Genie/Ort OM3e | | | | | ✓ | |
| RPM 1 Genie/Ort Alpha | | | | | ✓ | |
| RPM 1 Genie/Ort 2M Red | | | | | ✓ | |
| RPM 4/Pro K4 | | ✓ | ✓ | ✓ | | ** |
| RPM 4/AT AT95E | | ✓ | ✓ | ✓ | | ** |
| RPM 5 | | ✓ | ✓ | ✓ | | ** |
| RPM 5/Ort 2M Red | | ✓ | ✓ | ✓ | | ** |
| RPM 5 SP/Ort Salsa | | ✓ | ✓ | ✓ | | ** |
| RPM 5 SP/PJ Pick it MC1H | | ✓ | ✓ | ✓ | | ** |
| RPM 5/AT AT95E | | ✓ | ✓ | ✓ | | ** |
| RPM 5 SP/Ort X1-MC | | ✓ | ✓ | ✓ | | ** |
| RPM 6 | | | ✓ | ✓ | | ** |
| RPM 6 SB | ✓ | | | | | ** |
| RPM 9 | | | | | ✓ | |
| RPM 9X | | | | | ✓ | |
| RPM 9XP | | | | | ✓ | |
| RPM 10 | | | | | ✓ | |
| Studie | | | | | ✓ | |
| Perspective | | | | | ✓ | |
| Perspective SB | | | | | ✓ | |
| Perspective Anny/Sum Blue Point No.2 | | | | | ✓ | |
| Perspective II | | | | | ✓ | |
| 2.9 SP (Wood)/Sum Blue P No. 2 | | ✓ | ✓ | ✓ | | ** |
| 2.9 Wood | | ✓ | ✓ | ✓ | | ** |
| 2.9 Classic | | ✓ | ✓ | ✓ | | ** |
| 6 | | ✓ | ✓ | ✓ | | ** |
| 6.1 | | ✓ | ✓ | ✓ | | ** |
| 6.9 | | ✓ | ✓ | ✓ | | ** |
| 6.9 SP/Sum Blue P No.2 | | ✓ | ✓ | ✓ | | ** |

>>> meaning of characters/columns

| | |
|--|--|
| A | 78rpm capability out of the box |
| B | 78rpm possible by replacing original drive pulley for „78 Pulley Set“ to get 33 & 78 (no 45) |
| C | 78rpm possible by replacing original drive pulley for „Pulley SB“ and addition of Speed Box S (suitable for turntables with 16V AC motors) |
| D | 78rpm possible by replacing original drive pulley for „Pulley SB“ and addition of Speed Box SE (suitable for turntables with 230V and 16V AC motors) |
| E | 78rpm not possible (no pulley change possible) |
|  | not available for this turntable |
| ** | only available when suitable cartridge is mounted (exchanging cartridge is possible) |